

Tobacco Column Influence on Cigarette Paper


J. Wanna, C. Le Moigne, and L. Le Bec
SWM Intl.
100 North Point Center East
Suite 600
Alpharetta, GA 30022
USA

- 1 Introduction
- 2 Experimental
- 3 Results
- 4 Summary

- Cigarette paper has to be studied in context of the whole cigarette
- Tobacco affects cigarette paper prior to smoking
- Properties of both (tobacco & paper) impact cigarette smoking/burning characteristics
- SWM performed an earlier study on ion transfer from tobacco to cigarette paper¹
 - Cigarettes were stored at 22°C and 60%RH from 3 to 29 months
 - K ions transfers to cigarette paper at up to 0.17% after 6 months
 - No impact from Na ions
 - Malate, chloride, and nitrate also migrate to cigarette paper

¹T. Joyeux, G. Le Bourvellec, C. Le Moigne, and J. M. Loureau, "Migration of Cations and Anions from Tobacco into Cigarette Paper", Presentation at CORESTA 2006

Kinetic of cations migration¹




- High K migration up to 0.17% after 6 months ageing
- No Na migration (very low Na content in tobacco)

¹T. Joyeux, G. Le Bourvellec, C. Le Moigne, and J. M. Loureau, "Migration of Cations and Anions from Tobacco into Cigarette Paper", Presentation at CORESTA 2006

- This presentation will discuss:
 - Transfer of ions from the tobacco column to cigarette paper
 - Base and band diffusion at room temperature and after heating in an oven
- SWM made a presentation on the impact of filler and citrate on base and band diffusion at room temperature and after heating in an oven²

²J. Wanna and J.M. Loureau, "Band Diffusion at High Temperature", Presentation at TSRC 2011



Experimental

Experimental – Cigarette blends


- Two cigarette blends were selected: American blend (AM) and Virginia blend (VA)
- Select blend components were analyzed

Blend Analysis		
Analyte	VA	AM
Sugars (%)	12.6	8.4
Nicotine (%)	2.30	1.28
Nitrates (%)	0.44	1.59
Chloride (%)	0.67	1.50
Sulfate (%)	0.85	1.13
Potassium (%)	2.88	3.99
Organic Potassium (%)	1.75	1.7
Virginia	56%	33%
Recon	22%	22%
Burley	11%	29%
Oriental	11%	10%
Stem	0%	6%

Experimental – Cigarette base paper properties

Cigarette Paper Properties	Paper Porosity (CU)	Citrate (%)	BW (gsm)	Filler (%)	Fiber
Bobbin VA Blend (Control – VA)	75	2 K	24	26	Wood
Bobbin AM Blend (Control – AM)	60	0.80 Na/K	28	28	Wood

- Diffusion measurements performed using Sodim CO₂ Diffusivity Meter
- Lab condition at 50%RH and 23°C
- Binder oven was used to heat cigarette paper at 230°C for 30 minutes
- After heating, samples were conditioned in the lab for 30 minutes




Results: Cigarette Paper Ion Level

Results: Ion levels in cigarette paper and bobbin – VA blend

- Ion levels of cigarette paper from VA blend cigarettes compared to paper from bobbin (control)
- Minimal ion transfer among the measured constituents


	Cigarette Paper	Bobbin
	Cig. Pap. - VA	Bbn - VA
Sodium (%)	0.0733	0.0706
Potassium (%)	0.4678	0.4095
Citrate (%)	0.9063	0.7629
Chloride (%)	0.0294	0.0015
Nitrate (%)	0.0069	0.0030




Results: Ion levels in cigarette paper and bobbin – AM blend

- Ion levels of cigarette paper from AM blend cigarettes compared to paper from bobbin (control)
- Potassium, chloride, and nitrate ion increase in paper after contact with tobacco among the measured constituents.
- The lower K Citrate content in paper the higher the migration¹
- Other ions e.g. phosphate can also be transferred

	Cigarette Paper	Bobbin
	Cig. Pap. - AM	Bbn - AM
Sodium (%)	0.0486	0.0471
Potassium (%)	0.1312	0.0490
Citrate (%)	0.1535	0.1888
Chloride (%)	0.1293	0.0055
Nitrate (%)	0.0362	0.0001






Results: Cigarette Paper Diffusion

Results: Base paper diffusion at RT and high T

- RT D* for paper from bobbin used in AM blend cigarettes are slightly higher than D* for paper used with VA blend
- HT D* for paper used in VA blend cigarettes had higher increase (~24%) after heating compared to the increase (~12%) observed in paper from AM blend cigarettes
- Paper used with VA blend has higher potassium and ion

Code		Base D* (cm/sec)		
		Base RT	Base HT	Increase (%)
Bobbin	Cont - VA	1.200	1.478	23
Paper from Cig.	Cig - VA	1.114	1.408	26
Bobbin	Cont - AM	1.415	1.541	9
Paper from Cig.	Cig - AM	1.321	1.514	15

Results: Base paper diffusion at RT and high T





Results: Band diffusion at RT and high T

- RT D* for bands used in VA blend cigarettes were at 0.075cm/sec compared to D* of 0.045cm/sec for bands used with AM blend
- HT D* for bands removed from cigarette papers used with VA blend were 59% less compared to bands from cigarette paper off the bobbin
- HT D* for bands removed from cigarette papers used with AM blend were 81% less compared to bands from cigarette paper off the bobbin

Code		Band D* (cm/sec)		
		Band RT	Band HT	Increase (x)
Bobbin	Cont - VA	0.070	0.914	13.1
Paper from Cig.	Cig - VA	0.075	0.378	5.0
Bobbin	Cont - AM	0.045	0.687	15.3
Paper from Cig.	Cig - AM	0.053	0.128	2.5

Results: Band diffusion at RT and high T





Summary

- Tobacco columns impact cigarette paper and thus alters its decomposition pattern
- Higher level of ion transfer from American blend – higher % increase for potassium ions
- Transferred ions impact band diffusion after heating at high temperature
- The impact is larger for papers that were in contact with the American blend and also base paper had Na/K at lower level compare to paper used wit VA blend
- Cigarette paper properties studied after contacting tobacco column give better indication of its final performance

Acknowledgment

Thanks to Brian Nguyen who performed the diffusion measurements.

Thank You



Joe Wanna

SWM INTL

100 Northpoint Center East
Suite 600
Alpharetta, GA 30022
USA

swmintl.com